

## MODELS

## BOBRICK SURFACE MOUNTED CABINETS

<b>B3193279</b>	Bobrick Trimline™ 2-in-1 Surface Mounted Hand Dryer & Waste Bin
<b>B369039</b>	Bobrick Trimline™ 2-in-1 Surface Mounted Paper Towel Disp. & Waste Bin 790mm
<b>B380309</b>	Bobrick Trimline™ 3-in-1 Surface Mounted Paper Towel Disp., Dryer & Waste Bin 1449mm
<b>B380339</b>	Bobrick Trimline™ 3-in-1 Surface Mounted Paper Towel Disp., Dryer & Waste Bin 1415mm
<b>B38039</b>	Bobrick Trimline™ 2-in-1 Surface Mounted Paper Towel Disp. & Waste Bin 1400mm
<b>B390039</b>	Bobrick Trimline™ 2-in-1 Surface Mounted Paper Towel Disp. & Waste Bin 1420mm
<b>B8159699</b>	Bobrick Trimline™ 3-in-1 Surface Mounted Paper Towel Disp., Dryer & Waste Bin 1831mm

## Components supplied

- Recessed unit
- Conversion skirt

## Components/Tools required

- Drill and all relevant bits
- Suitable fixings to suit installation medium
- Spirit level

## Installation

To allow for maximum installation flexibility, installers are supplied with both the recessed unit and the skirt required to convert it into a surface-mounted unit. For surface-mounted installations, installers must drill their own fixing holes in both the skirt and the unit itself.

1. Lay skirting down on a soft, flat surface, lip side down.
2. Mark and drill holes for fixings on skirt. RBA recommends 2-3 fixings on each side of skirt.
3. Lay unit down on a soft, flat surface, door side up.
4. Open unit and remove the waste receptacle and any supplied documentation. If unit is equipped with a friction catch, you may experience some resistance the first time it is opened.
5. Close unit and flip over to reveal underside.
6. Mark and drill holes for fixings on underside of unit. RBA recommends 2-4 fixings behind the paper towel dispenser and 2-4 behind the waste receptacle.
7. Secure skirting to wall with suitable fixings [supplied by others], ensuring it is level.
8. Slide unit into skirting and secure in place with suitable fixings [supplied by others].
9. Replace waste receptacle.



