INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS

Note: This product should be installed, by suitably qualified persons, in a fit for purpose application, to suitable materials, using suitable fixings and comply with any relevant codes. It should be inspected periodically for signs of wear and tear that may affect performance or safety.

Dimensions are subject to manufacturer's tolerance of +/-10mm. Rough-in should be completed with each fixture.

Important: Installation Instructions are subject to change without notice.

Please visit www.rba.com.au for latest revision.





RBA8862-100

LEDGEBACK 'D' ROUND INSET BASIN





SYDNEY | MELBOURNE | BRISBANE | PERTH | AUCKLAND Australia 1300 788 778 www.rba.com.au | New Zealand 0800 722 111 www.rbagroup.co.nz SYDNEY | MELBOURNE | BRISBANE | PERTH | AUCKLAND

Australia 1300 788 778 www.rba.com.au | New Zealand 0800 722 111 www.rbagroup.co.nz

INSTALLATION

COMPONENTS

Single Stainless Steel Inset Basin Fixing Toggles Plug & waste (40mm BSP outlet)

NOTES

- 1) Installation should be carried out in accordance with all authority requirements, and as per these instructions.
- 2) Immediately on receipt, and before installation, check for marks or damage.
- 3) Designed for countertops up to 30mm thick.

ROUGH IN

1) Mark the location of the basin, or as determined by the builder/project manager.

2) Provide cut out 430mm in diameter

INSTALLATION

2

1) Attach fixing toggles to basin and fold back.

- 2) Mount basin and tighten fixing toggles.
- 3) Seal with silicon as required.
- 4) Attach Tapware (by others) and plug & waste to the basin.
- 5) Connect the wastes 40mm outlet to trap (provided by others) and drain away.



